

RHODES CHROMA (s10H

USING THE INTERFACE - - -

When you turn on the synthesiser for the first time, you will be in omni-on mode for receive (all channels) and channel 1 for transmit - See next page for factory default settings

When you select a transmit or receive channel, this will be stored in memory and will be remembered for when you subsequently turn on the synth - (omni on/off is also stored)

If you want to put the machine back to the factory default settings at any time, then switch the synth on whilst holding the red push button pressed - hold for a couple of seconds then release.

MODE CHANGE PUSH BUTTON

Pressing the button enters program mode. This enables you to program in such things as receive / transmit channel number information etc. Once you have entered program mode, the interface will stay in that mode until top C on the remote keyboard is pressed, and until that time, any key pressed on the remote keyboard will change a parameter.

MIDI SWITCH

For most purposes this switch can be left permanently in the on (down) position. This is the MIDI position, but if you wish to use the computer interface socket on the back of the Chroma, you must turn this switch off to disable the MIDI interface.

SENT	RECEIVED
notes on	notes on
notes off	notes off
velocity	velocity
program change	program change
pitchbend (lever 2)	pitchbend (lever 2)
mod wheel (lever 1 - pull)	mod wheel (as lever 1 - pull)
controller 4 (lever 1 - push)	controller 4 (as lever 1 - push)
sustain (footsw 2)	sustain (footsw 2)
	MIDI volume

C Receive channel 1 [Bottom C] MIDI note number 36

Db " " 2

D " " 3

Eb " " 4

E " " 5

F " " 6

Gb " " 7

G " " 8

Ab " " 9

A " " 10

Bb " " 11

B " " 12

C " " 13

Db " " 14

D " " 15

Eb " " 16

E Omni on mode (default)

F Transmit channel 1 (default)

Gb " " 2

G " " 3

Ab " " 4

A " " 5

Bb " " 6

B " " 7

C " " 8 [Middle C] MIDI note number 60

Db " " 9

D " " 10

Eb " " 11

E " " 12

F " " 13

Gb " " 14

G " " 15

Ab " " 16

A dump current program

Bb dump all programs

B not used - -

C not used - -

Db not used - -

D not used - -

Eb program change off

E " " ON (default)

F p.bend & mod wheel off

Gb p.bend ON (default)

G mod wheel ON (default)

Ab controller Y - ignored (see page 3 re controller Y)

A " - vcf

Bb " - *** (default)

B controller X - ignored (see page 3 re controller X)

C " - vcf (default)

Db " - ***

D aftertouch - ignored

Eb " - modulation (default)

E " - p.bend (up only)

F " - vcf

Gb " - *** (***) = not used on this synth)

G velocity - ignored (default)

Ab " - vcf

A " - vca

Bb MIDI volume - ignored

B " - vca (default)

C ENTER key - Press and release. [Top C] MIDI note no. 96

Selecting a receive channel will automatically put the MIDI into omni off mode. That is, it will receive on the selected channel only.

The transmit channel can be changed independently of the of the receive channel, and can be set even during omni on mode.

MIDI CONTROL OF RED PUSH BUTTON

The red push button can be "pressed" via MIDI as MIDI switch number 95 (5Fh) for regular program mode or 94 (5Eh) for transpose mode.

The selection of the push button is enough, it doesn't matter if it is being turned on or off.

In hexadecimal BX - 5F - 00 = program mode

In hexadecimal BX - 5E - 00 = transpose mode

Where X is the current MIDI channel.

[n.b. whilst in program/transpose modes the MIDI is in omni on mode]

MIDI CONNECTORS - -

MIDI IN should be connected to a MIDI OUT or a MIDI THRU similarly MIDI OUT should be connected only to a MIDI IN and a MIDI THRU should also be connected only to a MIDI IN.

MIDI OUT is the signal from the synthesiser (or drum machine etc.) that is to be sent to another instrument. MIDI IN is a received signal that contains MIDI information from another synth, and MIDI THRU is an exact copy of information arriving at the MIDI IN socket. This allows several instruments to be connected together.

If you want to wire your own MIDI cables the following information may be useful.

- 1) Although a 5 pin connector is used, only two connections plus an earth connection are required.
- 2) If you look at the din plug from the wiring side you will see that the pins are numbered. From left to right (or clockwise) these are 1 - 4 - 2 - 5 - 3.
- 3) The pins numbered 1 & 3 are not used.
- 4) The screen (earth) is connected to pin 2 (centre pin)
- 5) Pin 4 of one plug should be connected to pin 4 of the other
- 6) Pin 5 of one plug should be connected to pin 5 of the other
- 7) You should now have a working MIDI lead
- 8) It is preferable to label one end of the cable MIDI IN & the other end MIDI OUT, to avoid confusion.

Copyright (c) KENTON Electronics & John Price 1986-1992

Kenton Electronics
Rear of 137-165 Hook Road,
Surbiton
Surrey
KT6 5AR
Tel 081-974 2475
Fax 081-974 2485

CHRM4011/9209262052/JKP