



- #### SET SPLIT FUNCTIONS
- PATCH 0
 - OUTPUT 0
 - OUTPUT 1
 - OUTPUT 2
 - OUTPUT 3
 - BATTERY CHECK
 - KILL BAD BOARD
 - DISPLAY BAD BOARD
 - TAPPER ON/OFF
 - CASSETTE MODE
 - PROGRAM 0 PACKET
 - PROGRAM 1 PACKET
 - PROGRAM n PACKET
 - STOP PACKET
 - OUTPUT SUBROUTINE
- #### CC+ FUNCTIONS
- PERFORMANCE DISABLE
 - PERFORMANCE ENABLE
 - PANEL DISABLE
 - PANEL ENABLE
 - SEND PROGRAM
 - ATTACK THRESHOLD
 - RELEASE THRESHOLD
 - RELEASE SLOW RATE
 - RELEASE FAST RATE
 - BRANCH SUBROUTINE
 - MUTE A CHANNELS
 - MUTE B CHANNELS
 - UNMUTE
 - MUTE OSCILLATORS
 - TEST LED
 - (SPECIAL RESET)
 - (SPECIAL RESET #2)
 - (SPECIAL RESET #3)
 - PRESSURE DISABLE
 - PRESSURE ENABLE
 - CC+ PROG MODE ON/OFF
 - CC+ VOICE ALLOCATION
 - CC+ CREATE SCRATCH PATCH
 - CC+ AUTOTUNE INFO
 - SYNTECH PRGM MODE
 - SYNTECH CONFIG SYSX
 - SYNTECH BANK SYSX
 - SYNTECH MIDI PRGM 0
 - RESET MAIN COMPUTER
- BANK SELECT: PRG SEL + 1-4